





- 10.50 #W42 Lx or Speaker
- 10.50 #41
- 10.50 #40
- 10.30 #39 Rear Curtain
- 10.10 #38
- 9.70 #W37 Lx Bar #5
- 9.30 #36
- 9.10 #35
- 8.90 #34
- 8.70 #33
- 8.50 #32 Len.5
- 8.30 #31 Border.5
- 7.90 #W30 Lx Bar #4
- 7.50 #29
- 7.30 #28
- 7.10 #27
- 6.70 #26 LxM Curtain
- 6.50 #25 LxM.4
- 6.30 #24 Border.4
- 6.10 #23
- 5.70 #W22 Lx Bar #3
- 5.30 #21
- 5.10 #20
- 4.90 #19
- 4.70 #18
- 4.50 #17 Len.3
- 4.30 #16 Border.3
- 4.10 #15
- 3.90 #14
- 3.70 #13
- 3.50 #12
- 3.10 #W11 Lx Bar #2
- 2.70 #10
- 2.50 #9 Len
- 2.30 #8 Border.2
- 2.10 #7
- 1.90 #6
- 1.70 #5
- 1.50 #W4 Lx Bar #1A
- 1.10 #W3 Lx Bar #1
- 0.81 #2 Border.1 & Len.1
- 0.45 #1 House Tab

